English

RM-L1130+X PLUS Instruction for UNIVERSAL LCD/LED TV REMOTE CONTROLLER

Thank you for using our company remote controller products. When it is the first time to put in the batteries, please try it first. If it could work well with all of its functions, the product can be used directly without setup, if it could not work well, it should be set with the following methods before controlling your TV. This remote controller would not lose its memory when you change batteries, no need to reset.

Introduction

RM-L1130+X PLUS is the newest universal LCD/LED TV remote controller. Comprehensive care at different levels need, it can control old or new TV, famous brand or un-famous brand TV, nearly all models for TV.Commonly used functions and menu button all including. Easy setup, conveniently use, it is the best choice for your remote controller losing, damage, replacement, it will bring more convenient for your life.

Battery Installation

In accordance with the '+,-' symbols which is indicated inside the battery cabinet, open the cover and put into two new AAA (AAA) batteries (non-rationed), which is shown in the figure.



Battery Description

- The remote controller is a low-power consume product. The lifetime of batteries is about 12 months under normal circumstances. If it is improperly used or operated, the lifetime would be shortened.
- Please do not put old and new batteries or different types of batteries together.
- In case of battery leakage, the batteries must be removed and the battery cabinet should be cleaned before putting into new batteries.
- You'd better remove the batteries from the battery cabinet if you intend to stop using the remote controller for a long time.

Methods for setting remote controller:

This remote controller has the following methods for setup , you can choose any of them.

****

A.Inputting code:

1.Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV. Find the three digits code from the code list.

2.Press "SET" button, then press "POWER" button, till the indicator lamp lights, then release the buttons, the remote controller will be in the state of inputting code.

3. Enter the first set of three-digit code in order. When you input each digit, the indicator lamp will flash one time, when you enter all of the three digits, the indicator lamp will turn off., setting to be finished. If the code is more than one set, please use first one at first.

4.Test other function buttons can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

B.Manually searching for the code:

1.Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV.

2. Press "SET" button, then press "POWER" button, till the indicator lamp lights, then release the button, the remote controller will be in the state of Manually searching for the code.

3. Press the "VOLUME+" button one time, the indicator lamp will flash one time, please pay attention to your TV, see the volume symbol appears on your TV or not, if not, please repeat this procedure.

4. Till the volume symbol appears on your TV, test other function buttons (except SET, POWER, and VOLUME button) can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

C.Automatically searching code:

1. Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV.

2. Press and hold the "SET"button for about 6 seconds, till the indicator lamp lights, the remote controller will enter automatic search state,please pay attention to your TV, see the volume symbol appears on your TV or not, if yes, please release "SET" button at once, set finished.

3. Test other function buttons (except SET, POWER, and VOLUME button) can work well or not, such as "MUTE". If not, repeat steps 2 to 3, until you find the suitable code.

D.Point to Point Brand Searching:

1. Turn on your TV set, let your TV set be in the normal state play, and aim the remote controller in the front of the TV. Find out the corresponding brand of your TV on this remote control, for example, Telefunken = "0"

2. Press and hold the corresponding brand button for three seconds, the indicator lamp will flash, when the volume symbol appears on your TV, release button at once, the indicator lamp will turn off, set to be finished.

E.Restore factory Settings

Press "SET" button, then press "0", release the button, the indicator will flash two times, the remote controller restore factory Settings

Brand symbol table

NEW	MEDI	MITCI	LUX	JUST	TEST	TV	NONA	SID	SMSN
PHILIPS	JVC	DENON	NCE	Nokia	SKDI	SAMTO	RK	SONY	NANDA
SLIM	SUN	SMART	MEC	JEWEL	SANYO	SHARP	CLE	L	L
FUNAI	TC	AMBIENT	Rail	KONKA	TCL	SANDAND	LG	CRAY	Toshiba
[illegible]	[illegible]	[illegible]	[illegible]	[illegible]	[illegible]	[illegible]	[illegible]	[illegible]	
SAMP	TOSHIB	PHILIPS	ATECH	Hamp	SYNCHY	Telefunken	KOTEL		

000 AOC AOC
002 GENERAL LCD-831
003 GENERAL LCD-832
004 IZUMI TL19H405B
005 IZUMI 0152
006 EN 30303D
010 HOB301 MYSTERY KT6957 6857
011 HOB117 AKIRA TC1860F1
012 HOB187 GK23J6-C15
013 HOB279 AKIRA LCT-15CHST
014 4-3-2010-002
015 BBK BBK
016 BBK EN-31603B
017 HOB158 BBK LT1504
018 HOB332 BBK CAMERON
019 HOB380 RC2465
020 HOB387 RC-2603
021 HVD208 BBK
022 HVD209 RC1529
023 HOB228 LCD 831
024 HOB283 SUPRA 462ZSTV -LC1504
025 HOB302 HYUNDAI 1587 RCF1B
026 HOB303 SUPRA306 STV-LC1515
027 HOB327 Supra RC3b
028 HOB328 Supra RCF3b
029 HOB409 SUPRA Y-72C2
030 HOB410 SUPRA RC6b
031 HOB411 SUPRA RC12
032 RCF1B RCF1B
033 SUPRA BD-212
034 SUPRA HOF12H126 GPD11
035 SUPRA RC1b
036 SUPRA RC5b
037 SUPRA RC5db
038 SUPRA RC13b
039 SUPRA RC-118-0B

040 SUPRA STV-LC2615ED
041 HOB168 SHIVAKI BT0451C
042 HOB231 SHIVAKI 02
043 ROLSEN ER-31607R
046 HTC056 RC1994907-01
047 HTC058 RC198
048 HOB333 81E829
049 HOB394 81E503
050 HOB227 ORION
051 HOB252 OPENBOX -1253
052 HOB281 MYSTERY 5195
053 HOB282 MYSTERY 8151
054 HOB301 MYSTERY KT6957 6857
055 HOB326 MTV-1914LW
056 MESTERY LCD LED TV NEW
057 HSR499 HIVION
058 HOB402 iSTAR
059 HOB403 iSTAR
060 HOB405 iSTAR
061 ER-31607
062 HOB438 ER-31607R -1098#
063 LCD-2277RC
066 HOB302 HYUNDAI 1587 RCF1B
067 HOB376 H-LCD2202GCO VA1028SJ
068 HOB390 CH-2145
069 FUSION RC3b_1042
070 HOB198 FUNAI 48KEY
071 IR1628 FUNAIPC221
073 HOB018 ELENBERG Y27401
074 HOB354 ELENBERG
079 HOB151 BERICOM008
080 HOB189 HOB189
081 HOB264 RC-A3-01
082 HOB273 HOB273

RM-L1130+X PLUS

083 HOB373 EN-21662B
084 HOB223 RC-L-05
085 HOB225 RC-L-06
086 HOB108 ACH-P-2
087 HOB149 BERICOM006
088 HOB150 BERICOM007
089 HOB206 EL-41UA299
090 HOB329 T15E01MT
091 HOB330 H-LED32V6
092 HOB341 STV-LC1914W
093 HOB418 ZD-RC30
094 DMTECH DMTECH
095 HOB262 HOB262
096 HOB344 HOF45A1-2
097 HOB249 PARS
098 HOB292 H502-2
099 HOB013 HOF-54B1.4
100 HOB339 GI S2138
101 HOB381 HOF12E 148GPD5
102 HOB346 HOF10G 705GPD9
103 SONIQ QT-112
104 SUNSTECH TL1970HD
105 HOB195 H-LCDVD2200
106 HOB196 HOB196
107 HOB314 Singer LCDKZG -108
108 HOB386 RM-611
109 HOB308 IR1492 SENCOR
110 HOB310 HOB310
112 HOB342 STV -LC1985WL
113 HOB382 GI HOF12B441 GPD11
114 HOB220-NF021RD NF028RD-NF031RD -NF036RD 4IN1
115 NF039RD NF039RD
116 PC221 01
117 PC221 02
120 BC10SB BC10SB
121 daytron LCD TV
122 HOB358 RC-A03
123 RC A06
124 RC A10
125 TLCD 32HD-TELEFUNKEN
126 KAIMY KAIMY

127 acer acer
130 HOB162 BERICOM009
131 HOB187 GK23J6-C15
132 LCD-2699
133 HOB229 OPTICUM9600 TS20
134 HOB242 RC1994925
135 HOB253 SNOWA
136 HOB331 AKAI A4001032
137 HOB353 KM1128
138 HOB368 S5 S6 S7 S8 S9
139 LCD-2318
140 HOD142 HOD142
141 HOD148 VT-L9A11
142 HSR553 CYFROWY POLSAT
143 HSR585 IPM PLATFORM
144 Singer LCD TV 901-7650-315G1G
145 LCD TV FU-1
146 LCT 01
147 LCT 02
148 148 148
149 HOB393 1253
150 12-17-2011_001
151 AOC-01
152 AOC-02
153 BENQ-01
154 BENQ-02
155 BENQ-03
156 BENQ-04
157 BENQ-05
158 VIZIO
159 NEC RP-42L1
160 SANYO JXPYR
161 ROLSEN RL-32L700U
162 POLYTRON 81I579
163 SAM_2446
164 SAM_2443
165 SAM_2457
166 lcd tv
167 AKAI A3001012
168 AKAI CX-507
169 BBK EN-31907
170 CHANGHONG GHK-4421A
171 E-RCU-015

RM-L1130+X PLUS

348 BBK_ EN-31907
349 Benq
350 china
351 EcoStar 2
352 HCH067-CHANGHONG GHK-4421A
353 Heir 2
354 HOB477 AKAI CX-507
355 HOB478 E-RCU-015
356 HOB479 AKAI A3001012
357 HOB484 Akai LTA -15A15M
358 HOB489 MESTERY LCD LED TV NEW
359 HOB490 Polar HTR -D18A
360 HOB491 Polar 55 LTV6002
361 Orient
362 PROTON 2
363 POLYTRON EN-31618P 81E878
364 HOB864 SNOWA T202-1
365 HOB455 ELECTRON T-81100
366 HOB457 RL-32L700U 3D
367 HOB464 BRAVIS LED2868 HQ
368 HOB465 DIGITAL DLE-4011
370 HOB46 LUXEON LED3213 HQ
371 ORION EP 22 LCD2623
372 HOB493 HAIER
373 HOB494 SUPRA
374 HOB498 SHOWNIC
375 LEA-19V07P
376 IZUMI
377 81F579
378 ORION OR-LCD2
379 FUSION RC21b
380 SUPRA RC6w
381 SUPRA RC8b
382 SUPRA RC10w
383 SUPRA RC18b
384 RC-LEM100
385 BBK RC-LEM101
386 BBK RC-LED100
387 IZUMI_ TL26H211B
388 JAC
389 SKY LINE
390 TRUMAN
391 union tech

396 ATLAS HD100
397 HOB688 ATLSS HD-200S
398 KK-Y331J
399 KK-Y331J
400 HD LED100
401 GBTY ONGOV59
402 XY-B02E
403 LCD TV PHONAR
405 PHONAR LED TV
406 DAWA MV
407 iDEA
408 iDEA
409 iDEA
410 iDEA
411 iDEA
412 iDEA
413 iDEA
414 iDEA
415 AOC-02
416 DEX LT-2220
417 ORION LED2643
418 Akai SLP-006P
419 Fusion FLTV 22H11
420 Fusion FLTV 32H17
421 FUSION RC15b
422 Shivaki K77
423 Shivaki K78
424 Supra TV-DVD
426 RC-GK22G1
427 H-LCD3210
428 LED321LC
429 SKYPRIME HD
430 SUPRA RC21b-1219
431 ORION LCD
432 TC1860F1-RS
433 JH-11370
434 LED-851
435 RC-D3
436 YC-53
437 STV-22LED5
438 LED-EH4720BF
439 DNS M28AM8

RM-L1130+X PLUS

440 051D RED
441 33585
442 RC33729
442 HOB842
442 34090
442 34091
443 RC31277
444 Fusion RC25b
445 RCF23b
446 RC-E23
449 AKI AK61
450 AKI LCD AK66
451 AKI LCD AK68
452 AKI-OND IGO LCD
453 ONIDA LCD
454 ONIDA LCD ON87
516 051D BLACK
520 SNOWA 51163
528 BLAUPUNKT
531 J-1274
540 MERTER 33186
542 BRAVIS LED-1615
543 Marshal ME-2409
544 ONIDA LCD1
545 Akai HOF08J001
546 Polar 94 LTV6004
547 AN-LT3222 AN-LT3225 AN-LT2416
548 FUSION HY-079
549 SATURN LED40FHD500U
540 DEXP 16A3000
540 RUBIN RB -28D7T2C
550 DNS S19ASL1
551 RM-NST60
533 RM-SK09
576 AKIRA Mouse
577 Akira_ 32LED0172M
579 AKIRA 39LES0412P
580 BLAUPUNKT SMART TV
581 BLAUPUNKT LCD
582 BLAUPUNKT -1088#
583 BLAUPUNKT
584 Cloud Walker
586 cloudwalker

588 DAEWOO RC -670PN
589 DAEWOO RC -753BI
653 Hitachi CLE -1008
654 HITACHI RCA48105
676 JVC LCD LED TV REMOTE
677 JVC RM-C3401
679 JVC LCD-LED TV REMOTE
680 JVC LCD-LED TV REMOTE
681 JVC KT1157 -SX-1277#
684 RM-C3184
723 ONIDA SMART TV REMOTE 01
724 ONIDA SMART TV REMOTE 02
729 SANKEY 1
732 SANKEY 4
734 SANKEY 6
739 SANSUI ER -226418A
742 SANYO LCD TV REMOTE
743 SANYO LCD
745 SHARP GB236WJSA
746 SHARP GB289WJSA
747 RC5112
748 SHARP LCD TV EN3R395
749 SHARP LCD TV EN39K27S
751 SHARP EN2E28S
761 TCL RC311FM3
763 RC3100L07
770 Thomson RC311 USB
774 Toshiba CT-32F2
785 VU LCD TV REMOTE
787 VU SMART TV REMOTE
788 VU SMART TV REMOTE-02
796 VISION
797 VISION
798 VISION
799 VISION
811 Ecostar
812 ECOSTAR
823 RECONNECT LCD TV REMOTE
824 RECONNECT LCD TV REMOTE
825 VISE TV REMOTE
828 Willett LCD remote
829 WILLETT
836 Motorola Smart TV Remote